


SECTION 9: PARTS

Main



REF PART # DESCRIPTION



1	P1061001	MOTOR BASE
2	P1061002	MOTOR CASE
3	P1061003	FLAT HD SCR 5/16-18 X 1-1/4
4	P1061004	STATOR (G1061)
4	P1061Z004	STATOR (G1061Z)
5	P1061005	ROTOR (G1061)
5	P1061Z005	ROTOR (G1061Z)
7	P1061007	MOTOR FAN
8	P1061008	BALL BEARING 6206ZZ
9	P1061009	END BELL
10	P1061010	LOCK WASHER 1/4
11	P1061011	PHLP HD SCR 1/4-20 X 5/8
12	P1061012	CORD CLAMP
13	P1061013	POWER CORD 16G X 3W 73L
14	P1061014	STRAIN RELIEF
15	P1061015	PHLP HD SCR 10-24 X 1/2
16	P1061016	SWITCH PANEL
17	P1061017	LOCK WASHER #10
18	P1061018	ON/OFF SWITCH

REF PART # DESCRIPTION

19	P1061019	LOCK WASHER 5/16
20	P1061020	HEX NUT 5/16-18
21	P1061021	TAP SCREW #6 X 1/2
22	P1061022	CLAMP
23	P1061023	S CAPACITOR 400M 125V 1-3/4 X 3-3/8 (G1061Z)
23-1	P1061123-1	S CAPACITOR 300M/125V 1-3/4 X 3-3/8 (G1061)
24	P1061024	CLAMP CORD
25	P1061025	FLOOR PLATE
26	P1061026	FOOT WASHER
27	P1061027	FLAT WASHER #10
28	P1061028	PHLP HD SCR 10-24 X 1/2
29	P1061029	WHEEL FLANGE 5/8 BORE
30	P1061030	HEX NUT 5/8-11 LH
31	P1061031	HEX NUT 5/8-11 RH
33	P1061033	CENTRIFUGAL SWITCH 3450 RPM (G1061)
33	P1061033	CENTRIFUGAL SWITCH 3450 RPM (G1061)
34	P1061034	CONTACT SWITCH PLATE
35	P1061035	T-BUSHING 1 X 3/4 X 3/8
49	P1061049	T-BUSHING 3/4 X 5/8 X 5/16



Labels & Cosmetics



Grizzly Industrial **MODEL G1061 BUFFER/GRINDER**

Specifications	⚠ WARNING!
Motor: 1 HP, 115V, 1-Ph, 60 Hz Full-Load Current Rating: 14A Motor Speed: 3450 RPM Max. Wheel Diameter: 12" Buffing Wheel Arbor: 5/8" Buffing Wheel Max. Width: 2" Weight: 53 lbs.	To reduce risk of serious personal injury when using this machine: 1. Read & understand owner's manual before operating. 2. Always wear approved eye protection and respirator. 3. Only plug power cord into a grounded outlet. 4. Never place hands on rotating buffing wheel. 5. Do not wear loose clothing, gloves, or jewelry. Secure long hair and button all long-sleeve shirts. 6. Always disconnect power before changing wheels or adjusting. 7. Do not operate under the influence of drugs or alcohol. 8. Make sure machine is properly adjusted and set up correctly before starting motor. 9. Make sure machine is secured to a stable surface before starting. 10. Keep a firm grip on the workpiece and ensure it is properly supported throughout the buffing operation. 11. Do not use workpiece with nails, loose knots, splinters or any condition that may cause the wheel to grab and project workpiece. 12. Prevent unauthorized use by children or untrained users.

Date
 S/N
Mfd. for Grizzly in Taiwan

Grizzly Industrial **MODEL G1061Z BUFFER/GRINDER**

Specifications	⚠ WARNING!
Motor: 1 HP, 115V, 1-Ph, 60 Hz Full-Load Current Rating: 14A Motor Speed: 1725 RPM Max. Wheel Diameter: 12" Buffing Wheel Arbor: 5/8" Buffing Wheel Max. Width: 2" Weight: 53 lbs.	To reduce risk of serious personal injury when using this machine: 1. Read & understand owner's manual before operating. 2. Always wear approved eye protection and respirator. 3. Only plug power cord into a grounded outlet. 4. Never place hands on rotating buffing wheel. 5. Do not wear loose clothing, gloves, or jewelry. Secure long hair and button all long-sleeve shirts. 6. Always disconnect power before changing wheels or adjusting. 7. Do not operate under the influence of drugs or alcohol. 8. Make sure machine is properly adjusted and set up correctly before starting motor. 9. Make sure machine is secured to a stable surface before starting. 10. Keep a firm grip on the workpiece and ensure it is properly supported throughout the buffing operation. 11. Do not use workpiece with nails, loose knots, splinters or any condition that may cause the wheel to grab and project workpiece. 12. Prevent unauthorized use by children or untrained users.

Date
 S/N
Mfd. for Grizzly in Taiwan

REF	PART #	DESCRIPTION
101	P1061101	4-WAY WARNING LABEL
102	P1061102	ELECTRICITY WARNING LABEL
103	P1061103	MACHINE ID LABEL (G1061)

REF	PART #	DESCRIPTION
103	P1061Z103	MACHINE ID LABEL (G1061Z)
104	P1061104	TOUCH-UP PAINT, GRIZZLY GREEN

⚠ WARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or www.grizzly.com.

